

Care and Cleaning Guide

PRODUCTS WITH PERMABLOK³®, & PERMAGUARD[®]

Spradling[®] products are in its majority protected by PERMABLOK³® or PERMAGUARD[®], two of the most effective defence systems against germs, stains and abrasion. Two impermeable barriers to safeguard your investment. For optimum care and cleaning please read the following instructions and recommendations.

Disinfectant Use:



The information published in this care guide refers to the performance of PERMABLOK³® and PERMAGUARD[®] products in specific tests conducted under laboratory conditions. Results may vary under actual conditions.

- Asepticare TB + II
- Antifect (in 0.5 % dilution)
- Caviwipes XL Packed
- Cleanisept Wipes
- Clorox Healthcare Bleach Germicidal Wipes
- Coverage Plus Germicidal Wipes
- Desomed rapid
- FD 366
- Hydrogen Peroxide Cleaner Disinfectant Wipes
- Instrunet Anionsurf
- Lysol Foaming Disinfectant Cleaner
- Microzid
- Oxivir TB Wipes
- Oxycide Diluted –3oz/gl in water
- PDI Sani-cloth bleach wipes
- Sanicloth AF 3
- Sodium Hypochlorite: Disinfectant Bletach cleaner. Dilution: 1:10 mix of bleach and water.
- Surfanios Premium (in 0,25% dilution)
- Surfa'Safe Premium (in 0,25% dilution)
- Super Sani-cloth
- Virex II 256 (1:256 Dilution)
- Virox 5 Rtu
- Wet wipe
- Wex Cide 128 (1:128 dilution)

Spradling[®] Europe is not sponsored by, affiliated with, or endorsed by the above trademark owners. Additionally, any use by Spradling[®] Europe of any third-party trademark does not constitute any endorsement by Spradling[®] Europe of such third parties.

Rinse the area with clean water; then dry with a clean, lint-free cloth after using any disinfectants and cleaners.

Cleaning After Disinfection:



The coated fabric should be cleaned periodically in order to maintain its appearance and prevent build-up of dirt and contaminants. Any stain, spills, or soiling should be cleaned up immediately to prevent the possibility of permanent staining.

Use a mixture of liquid soap (neutral pH) and water or [our approved cleaning products for coated fabrics](#) to remove stains on the surface of the material. Remove only with a damp white cloth. Lacquers, strong cleaners, detergents, xylene-based solutions, acetone, or ketone (MEK) cause immediate damage and contribute to the deterioration of the material. The use of such cleaners is at the owner's risk.

Daily Cleaning

1. Clean the entire surface using a mixture of 1:1 liquid soap (neutral pH) and water. Do not use soap or cleaning solutions that contain alcohol, ketones, xylene, acetates or solvents (mineral/white spirits).
2. Completely remove excess cleaner with a white, clean, damp cloth.
3. Dry the surface.

Cleaning methods to remove tougher stains

- **Step 1:** Coffee, juice, red wine, sauces, chocolate, grease, crayon and suntan lotion. Remove excess spill with a damp cloth. Clean with a 1:1 mix of neutral liquid soap and water. Next, rinse with clean water and dry.
- **Step 2:** Make-up Use a straight application of neutral PH soap. Wipe with a clean white cloth or soft brush, rinse with clean water, and dry.
- **Step 3:** Blood, urine, faeces and all other tough stains Use a 1:10 mix of Isopropyl alcohol and water. Rinse thoroughly with clean water and dry.

Note: For cleaning use a soft white cotton cloth saturated with the recommended cleaning agent and rub the stain in circles 10 times. Pat dry with another soft white cotton cloth and check the results. Do not use steel bristle brushes, abrasive scouring pads or metal, these cause permanent damage to the fabric.

Methods 2 & 3 are not recommended for everyday cleaning!

After cleaning, rinse the area with clean water; then dry with a clean, lint-free cloth. Failure to remove chemical residue will cause discoloration of the coated fabric surface to manifest earlier in the life cycle of the product.

Resources:

- [Click here to discover our PERMABLOK³® Coated Fabrics](#)
- [Click here to discover our PERMAGUARD[®] Coated Fabrics](#)

All other products:

For products other than PERMABLOK³® & PERMAGUARD[®] follow the steps of Cleaning after disinfection as mentioned above but avoid the use of Isopropyl alcohol (as mentioned in Step 3).

The information published in these care guides refer to the performance of Spradling[®] Europe products in specific tests conducted under laboratory conditions. Results may vary under actual conditions. This information is not a guarantee and does not relieve the user from the responsibility of the proper and safe use of the product and all cleaning agents. The use of certain agents can be harmful to the surface appearance and lifespan of coated fabrics. To promote a long product life, it is recommended that the Spradling[®] Europe cleaning and maintenance protocol be employed regularly. Spradling[®] Europe, its agents and assigns assume no responsibility resulting from the use of such cleaning agents to the coated fabric. Inclusion in this document does not imply "fit for use." Customers should first determine if products are appropriate for use on their surfaces. Spradling[®] Europe cannot be held responsible for failure to follow proper cleaning protocol, or the use of improper cleaners that result in surface damage or colour change. Certain clothing and accessory dyes (such as those used on denim jeans) may migrate to lighter colours. This phenomenon is increased by humidity and temperature and is irreversible. Spradling[®] Europe will not assume responsibility for dye transfer caused by external contaminants and possible permanent staining caused by this phenomenon.



GERMANY:

Tel: +49 (0)4131 7098 4000
Fax: +49 (0)4131 7098 4010

✉ info.de@spradling.eu

SPAIN:

Tel: +34 938 655 719
Fax: +34 938 627 960

✉ info.es@spradling.eu

UNITED KINGDOM:

Tel: +44 (0)1235 812 329
Fax: +44 (0)1235 815 051

✉ info.uk@spradling.eu

www.spradling.eu